













- i Please review all available spare parts for this item, then contact us through the webform (found in the Help Centre in our website header). Let us know the SKU of each spare part you're interested in and the quantity you need.
- i The availability of the products may change.

Product image	SKU number	Product name	Available quantity
	19001016	<ul style="list-style-type: none"> 🇵🇱 POKRYWA BATERII SBS-ZW-3001H (gładkie) 🇬🇧 BATTERY COVER (SMOOTH) 🇩🇪 Batteriefachdeckel glatt 	● 24
	19001730	<ul style="list-style-type: none"> 🇵🇱 AKUMULATOR 6V4AH 🇬🇧 Akku 🇩🇪 battery PRODUCENT 	● 0
	19010916	<ul style="list-style-type: none"> 🇵🇱 Zasilacz 8V 🇬🇧 500mA 🇩🇪 Adapter 8V 	● 1
	19010917	<ul style="list-style-type: none"> 🇵🇱 Zasilacz 9V 🇬🇧 500mA 🇩🇪 Adapter 9V 	● 0
	19013389	<ul style="list-style-type: none"> 🇵🇱 Szalka plastikowa 🇬🇧 Plastic pan 	● 7

Product image	SKU number	Product name	Available quantity
	19013896	 Moduł główny  Main module	 0
	19014616	 Wyświetlacz  Display	 1
	19026140	 Obudowa plastikowa dolna  Plastic bottom housing	 3