















- i Please review all available spare parts for this item, then contact us through the webform (found in the Help Centre in our website header). Let us know the SKU of each spare part you're interested in and the quantity you need.
- i The availability of the products may change.

Product image	SKU number	Product name	Available quantity
	19015163	🇵🇱 Bezpiecznik 10A 🇬🇧 10A fuse	● 2
	19015164	🇵🇱 Pierścień uszczelniający 🇬🇧 Sealing ring	● 0
	19015165	🇵🇱 Grzałka 🇬🇧 Heater	● 1
	19015190	🇵🇱 Czujnik temperatury 🇬🇧 Temperature sensor	● 1
	19015195	🇵🇱 Tyrystor 🇬🇧 Thyristor	● 0

Product image	SKU number	Product name	Available quantity
	19027470	<ul style="list-style-type: none">  Moduł sterowania FS-FCD-6006  Control module FS-FCD-6006 	<ul style="list-style-type: none"> ● 0
	19028691	<ul style="list-style-type: none">  Manometr próżniowy (wakuometr) -1 do 0 BAR  Vacuum manometer -1 do 0 BAR 	<ul style="list-style-type: none"> ● 0
	19029245	<ul style="list-style-type: none">  Płyta PCB 76*76*50mm  PCB 76*76*50mm 	<ul style="list-style-type: none"> ● 18