

- i** Please review all available spare parts for this item, then contact us through the webform (found in the Help Centre in our website header). Let us know the SKU of each spare part you're interested in and the quantity you need.
- i** The availability of the products may change.

Product image	SKU number	Product name	Available quantity
	19001590	<ul style="list-style-type: none">  PANEL PRZEDNI  front panel  Vorderpanel Proclean 3.0 	5
	19001591	<ul style="list-style-type: none">  PANEL KONTROLNY LED  touch control panel  Kontrollpanel 	7
	19004252	<ul style="list-style-type: none">  GRZAŁKA NOWA WERSJA  Heizelement neue Variante  Heating Element New Version PROCLEAN 10.0 28.0 	24
 <small>Nowa wersja koszyka, posiada stałe uchwytowanie i funkcję łatwego i bezpiecznego wyjmowania. Nowe wymiary. Dostępny z numerem 19004546 i większymi wymiarami.</small>	19004546	<ul style="list-style-type: none">  KOSZ NOWY TYP  basket new type  Korb neuer Typ PROCLEAN 28.0 	3
	19008198	<ul style="list-style-type: none">  Pokrywa metalowa  Metal lid 	1

Product image	SKU number	Product name	Available quantity
	19008199	<p> Opakowanie zewnętrzne 42x65x46</p> <p> Outer packaging 42x65x46</p>	● 0
	19019141	<p> Płytki 4C9745-1</p> <p> board 4C9745-1</p>	● 3
	19025808	<p> Płyta główna DR1530MB-V1.3</p> <p> DR1530MB-V1.3 main board</p>	● 1
	19027460	<p> Płyta główna EMMI-D-V.0623</p> <p> Main board EMMI-D-V.0623</p>	● 3