




- i** Please review all available spare parts for this item, then contact us through the webform (found in the Help Centre in our website header). Let us know the SKU of each spare part you're interested in and the quantity you need.
- i** The availability of the products may change.

Product image	SKU number	Product name	Available quantity
	19009794	<p>🇵🇱 Kosz metalowy</p> <p>🇬🇧 Metal basket</p>	● 11
	19012322	<p>🇵🇱 Nóżka gumowa</p> <p>🇬🇧 Rubber feet</p>	● 6
	19018016	<p>🇵🇱 Płyta główna</p> <p>🇬🇧 Main board</p>	● 2
	19018017	<p>🇵🇱 Panel sterowania</p> <p>🇬🇧 Control board</p>	● 1
 <div data-bbox="290 1809 386 2020"> <p>NEW TYPE</p> <p>PCB main upgraded by supplier (both types are replaceable)</p> <p>NEW TYP</p> <p>PCB main upgraded by supplier (both types are replaceable)</p> </div>	19025756	<p>🇵🇱 Płyta główna 4C9745-1</p> <p>🇬🇧 Main board 4C9745-1</p>	● 0

Product image	SKU number	Product name	Available quantity
	19027459	 Płyta główna EMMI-D-V.0623  Main board EMMI-D-V.0623	● 0
	19028861	 Płyta PCB z wyświetlaczem  PCB board with display	● 0