

- i Please review all available spare parts for this item, then contact us through the webform (found in the Help Centre in our website header). Let us know the SKU of each spare part you're interested in and the quantity you need.
- i The availability of the products may change.

Product image	SKU number	Product name	Available quantity
	<b>19028541</b>	<ul style="list-style-type: none"> <li> Zawór regulujący</li> <li> Regulating valve</li> </ul>	<span style="color: red;">●</span> <b>0</b>
	<b>19028745</b>	<ul style="list-style-type: none"> <li> Czujnik ciśnienia HK12-P123</li> <li> Pressure sensor HK12-P123</li> </ul>	<span style="color: green;">●</span> <b>1</b>
	<b>19028746</b>	<ul style="list-style-type: none"> <li> Przewód czujnika ciśnienia ze złączami</li> <li> Pressure sensor cable with connectors</li> </ul>	<span style="color: green;">●</span> <b>2</b>
	<b>19028850</b>	<ul style="list-style-type: none"> <li> Płytkę wyświetlacza</li> <li> Display board</li> </ul>	<span style="color: green;">●</span> <b>1</b>
	<b>19029185</b>	<ul style="list-style-type: none"> <li> Uszczelka tłoka (Śr. 48 x 68 x 0.9)</li> <li> Piston seal (Size: di48 x 68 x 0.9)</li> </ul>	<span style="color: green;">●</span> <b>2</b>

Product image	SKU number	Product name	Available quantity
	<b>19029889</b>	 Zawór elektromagnetyczny 3V1-06  Solenoid valve 3V1-06	 <b>1</b>