






- i Please review all available spare parts for this item, then contact us through the webform (found in the Help Centre in our website header). Let us know the SKU of each spare part you're interested in and the quantity you need.
- i The availability of the products may change.

Product image	SKU number	Product name	Available quantity
	19015866	<ul style="list-style-type: none">  Rożen kompletny  Spit complete 	● 0
	19016533	<ul style="list-style-type: none">  Uchwyty plastikowe  Plastic handles 	● 0
	19017364	<ul style="list-style-type: none">  Taca ociekowa  Drip tray 	● 0
	19021787	<ul style="list-style-type: none">  Szyba do grilla  Grill glass 	● 2
	19022040	<ul style="list-style-type: none">  Grzałka 230V  890W  Heating element 230V 	● 0

Product image	SKU number	Product name	Available quantity
	19022618	 Lewa obudowa  Left housing	 0