











- i Please review all available spare parts for this item, then contact us through the webform (found in the Help Centre in our website header). Let us know the SKU of each spare part you're interested in and the quantity you need.
- i The availability of the products may change.

Product image	SKU number	Product name	Available quantity
	<b>19017113</b>	<ul style="list-style-type: none"> <li> Żeliwny trzpień łączący</li> <li> Cast iron connecting pin</li> </ul>	<span style="color: red;">●</span> <b>0</b>
	<b>19017130</b>	<ul style="list-style-type: none"> <li> Skrzynka kontrolna 2.2 kW 3HP 2850r</li> <li> min</li> <li> Control box 2.2 kW 3HP 2850r</li> </ul>	<span style="color: green;">●</span> <b>4</b>
	<b>19029053</b>	<ul style="list-style-type: none"> <li> Kołnierz przyłączeniowy gwintowany</li> <li> Threaded connection collar</li> </ul>	<span style="color: red;">●</span> <b>0</b>