





- i Please review all available spare parts for this item, then contact us through the webform (found in the Help Centre in our website header). Let us know the SKU of each spare part you're interested in and the quantity you need.
- i The availability of the products may change.

Product image	SKU number	Product name	Available quantity
	19020668	🇵🇱 Dźwignia przepustnicy 🇬🇧 Throttle Lever	● 0
	19020669	🇵🇱 Linka przepustnicy 🇬🇧 Throttle Cable	● 0
	19020670	🇵🇱 Dźwignia sterowania sprzęgłem 🇬🇧 Clutch Control Lever	● 0
	19020671	🇵🇱 Linka sterowania sprzęgłem 🇬🇧 Clutch Control Cable	● 0
	19020672	🇵🇱 Dźwignia dolna 🇬🇧 Down Lever	● 0

Product image	SKU number	Product name	Available quantity
	19020673	<p> Linka kierownicza prawa</p> <p> lewa</p> <p> Right</p>	● 0
	19020674	<p> Złącze kablowe</p> <p> Dumper Box Cable</p>	● 0
	19020675	<p> Pasek</p> <p> B-Belt</p>	● 0
	19020676	<p> Lewo koło</p> <p> Left Wheel</p>	● 0
	19020677	<p> Prawe koło</p> <p> Right Wheel</p>	● 0
	19024496	<p> Uchwyt mocowania dźwigni</p> <p> Lever Mount Bracket (code: 09710.37.012)</p>	● 0

Product image	SKU number	Product name	Available quantity
	19024497	<p>🇵🇱 Obudowa wału wyjściowego</p> <p>🇬🇧 Output Shaft House (code: 09615.37.148-2)</p>	● 0