

- i Please review all available spare parts for this item, then contact us through the webform (found in the Help Centre in our website header). Let us know the SKU of each spare part you're interested in and the quantity you need.
- i The availability of the products may change.

Product image	SKU number	Product name	Available quantity
	19005150	<ul style="list-style-type: none"> i  SZALKA  WIEGEPLATTE  PAN TEKO+LED06T-PLS-B1 	● 5
	19005153	<ul style="list-style-type: none"> i  AKUMULATOR 6V 4.5AH  AKKU 6V 4.5AH  BATTERY 6V 4.5AH TEKO+LED06T-PLS-B1 	● 0
	19006940	<ul style="list-style-type: none"> i  Płyta główna MP23.2-29R1  main board MP23.2-29R1  Hauptplatine MP23.2-29R1 	● 0
	19007858	<ul style="list-style-type: none"> i  Czujnik tensometryczny  Load cell 	● 0
	19008039	<ul style="list-style-type: none"> i  Kabel transmisyjny  transmission cable 	● 42

Product image	SKU number	Product name	Available quantity
	19008196	<ul style="list-style-type: none">  Opakowanie zewnętrzne 34x33x20  Outer packaging 34x33x20 	<ul style="list-style-type: none"> ● 3
	19018640	<ul style="list-style-type: none">  Podstawa plastikowa  Plastic base 	<ul style="list-style-type: none"> ● 1
	19028681	<ul style="list-style-type: none">  Naklejka panelu przedniego z zakresem ważenia  Front panel sticker with weighing range for weighing scale 	<ul style="list-style-type: none"> ● 0