











- i Please review all available spare parts for this item, then contact us through the webform (found in the Help Centre in our website header). Let us know the SKU of each spare part you're interested in and the quantity you need.
- i The availability of the products may change.

Product image	SKU number	Product name	Available quantity
	<b>19007059</b>	<ul style="list-style-type: none"> <li> Kabel transmisyjny RS - 232</li> <li> transmission cable RS - 232</li> <li> Übertragungskabel RS - 232</li> </ul>	<span style="color: green;">●</span> <b>20</b>
	<b>19020214</b>	<ul style="list-style-type: none"> <li> Obudowa przód z klawiaturą</li> <li> Front cover with keyboard</li> </ul>	<span style="color: green;">●</span> <b>1</b>
	<b>19021197</b>	<ul style="list-style-type: none"> <li> Czujnik tensometryczny 100 kg</li> <li> Load cell 100 kg</li> </ul>	<span style="color: green;">●</span> <b>3</b>