











- i Please review all available spare parts for this item, then contact us through the webform (found in the Help Centre in our website header). Let us know the SKU of each spare part you're interested in and the quantity you need.
- i The availability of the products may change.

Product image	SKU number	Product name	Available quantity
	<b>19005136</b>	<ul style="list-style-type: none"> <li> WYŚWIETLACZ LCD</li> <li> LCD ANZEIGE</li> <li> LCD DISPLAY BEKO+LCD035x040150-B1</li> </ul>	<span style="color: green;">●</span> <b>11</b>
	<b>19008504</b>	<ul style="list-style-type: none"> <li> Moduł z wyświetlaczem</li> <li> Module with display</li> </ul>	<span style="color: red;">●</span> <b>0</b>
	<b>19011276</b>	<ul style="list-style-type: none"> <li> Szalka aluminiowa</li> <li> Aluminum pan</li> </ul>	<span style="color: green;">●</span> <b>13</b>