





- i Please review all available spare parts for this item, then contact us through the webform (found in the Help Centre in our website header). Let us know the SKU of each spare part you're interested in and the quantity you need.
- i The availability of the products may change.

| Product image | SKU number | Product name | Available quantity |
|---|-----------------|--|---|
|  | 19009318 | <ul style="list-style-type: none"> 🇵🇱 Klucz imbusowy z plastikowym uchwytem 3mm 🇬🇧 Allen key with plastic handle 3mm | ● 4 |
|  | 19009761 | <ul style="list-style-type: none"> 🇵🇱 Zasilacz 🇬🇧 Adapter | ● 3 |
|  | 19020230 | <ul style="list-style-type: none"> 🇵🇱 Płyta główna KD-DC200A-ST1 \ 🇬🇧 Motherboard KD-DC200A-ST1 | ● 1 |
|  | 19025026 | <ul style="list-style-type: none"> 🇵🇱 Bateria 36V 🇬🇧 Battery 36V | ● 5 |