

- i** Please review all available spare parts for this item, then contact us through the webform (found in the Help Centre in our website header). Let us know the SKU of each spare part you're interested in and the quantity you need.
- i** The availability of the products may change.

Product image	SKU number	Product name	Available quantity
	19000600	<ul style="list-style-type: none">  Stycznik trójfazowy  Three phase cable connector 	● 0
	19010700	<ul style="list-style-type: none">  Bezpiecznik termiczny resetowalny WKD-115  Resettable thermal fuse WKD-115 	● 24
	19012420	<ul style="list-style-type: none">  kostka elektryczna  Electric cube 	● 0
	19013363	<ul style="list-style-type: none">  Grzałka  Heater 	● 0
	19013941	<ul style="list-style-type: none">  Pokrętło resetu  Reset knob 	● 0

Product image	SKU number	Product name	Available quantity
	19014655	<p>🇵🇱 Klapka z tabliczką znamionową</p> <p>🇬🇧 Flap with nameplate</p>	● 1
	19015998	<p>🇵🇱 Timer 180 min</p> <p>🇬🇧 180 min timer</p>	● 0
	19017975	<p>🇵🇱 Osłona grzałki</p> <p>🇬🇧 Heater cover</p>	● 6
	19018759	<p>🇵🇱 Termostat z kapilarą</p> <p>🇬🇧 Thermostat with capillary</p>	● 0
	19019642	<p>🇵🇱 Osłona dolna</p> <p>🇬🇧 Bottom cover</p>	● 5