









- i Please review all available spare parts for this item, then contact us through the webform (found in the Help Centre in our website header). Let us know the SKU of each spare part you're interested in and the quantity you need.
- i The availability of the products may change.

Product image	SKU number	Product name	Available quantity
	19010700	<p> Bezpiecznik termiczny resetowalny WKD-115</p> <p> Resettable thermal fuse WKD-115</p>	● 24
	19013363	<p> Grzałka</p> <p> Heater</p>	● 0
	19026326	<p> Wspornik metalowy</p> <p> Metal bracket</p>	● 0
	19026958	<p> Termostat KSD307 250V 60A 115C</p> <p> Thermostat KSD307 250V 60A 115C</p>	● 0