
















- i** Please review all available spare parts for this item, then contact us through the webform (found in the Help Centre in our website header). Let us know the SKU of each spare part you're interested in and the quantity you need.
- i** The availability of the products may change.

Product image	SKU number	Product name	Available quantity
	19014915	<ul style="list-style-type: none">  Podstawa metalowa kompletna  Complete metal base 	● 4
	19014950	<ul style="list-style-type: none">  Siłownik (podnośnik)  Actuator (lifter) 	● 12
	19015074	<ul style="list-style-type: none">  Podstawa metalowa okrągła  Metal round base 	● 4
	19016024	<ul style="list-style-type: none">  Siedzisko  The seat 	● 0
	19018518	<ul style="list-style-type: none">  Dźwignia regulacji wysokości  Height adjustment lever 	● 1

Product image	SKU number	Product name	Available quantity
	19020530	 Śruba imbusowa [D]  Allen screw [D]	● 12
	19022206	 Hoker kompletny  Complete stool	● 2