













- i** Please review all available spare parts for this item, then contact us through the webform (found in the Help Centre in our website header). Let us know the SKU of each spare part you're interested in and the quantity you need.
- i** The availability of the products may change.

| Product image   | SKU number      | Product name   | Available quantity   |
|---|-----------------|--|--|
|    | <b>19014562</b> |  Noga drewniana przednia<br> Wooden front leg    |  <b>0</b>   |
|   | <b>19015812</b> |  Dolna osłona siedziska<br> Lower seat cover |  <b>2</b> |
|  | <b>19025878</b> |  Zestaw montażowy<br> Assembly kit           |  <b>0</b> |