expondo


SKU 10010730 Spare parts

List of available spare parts and related products



23/11/2026


Please review all available spare parts for this item, then contact us through the webform (found in the Help Centre in our website header). Let us know the SKU of each spare part you're interested in and the quantity you need.

The availability of the products may change.

Product image	SKU number	Product name	Available quantity
	**19000137**	Noodle Cooker Thermostat Termostat WYE-110F	**0**
	**19000138**	Noodle Cooker Temp Limiter Termo-bezpiecznik WQS-135	**0**
	**19002038**	Nóżka gumowa Rubber feet	**9**
	**19004066**	SZUFLADA na resztki tłuszczu Schublade für die Fettreste drawer for the fat residue RCRO-1300	**4**
	**19004088**	TERMOSTAT THERMOSTAT THERMOSTAT RCRO-1300	**0**

Product image	SKU number	Product name	Available quantity
	**19004118**	POKRĘTŁO TIMERA TIMER-Drehknopf TIMER KNOB RCPO-2000-1PE	**8**
	**19004119**	TARCZA TIMERA 120 Scheibe des Timers 120 schield of the timer 120 RCPO-2000-1PE	**2**
	**19004120**	TIMER 120 RCPO-2000-1PE	**13**
	**19004227**	GRZAŁKA Heizelemnt Heater RCRO-1300	**0**
	**19004363**	KRATKA GITTER GRATE RCRO-1300	**12**
	**19004371**	UCHWYT GRIFF HANDLE RCRO-870	**12**

Product image	SKU number	Product name	Available quantity
	**19004470**	PÓŁKA DOLNA Unteres Fach bottom shelf RCRO-1300	**1**
	19004476	NÓŻKA FUSS FEET RCRO-1300	**0**
	**19004634**	MODUŁ STERUJĄCY Steuereinheit controlbox RCRO-870	**0**
	**19004671**	TERMOMETR Thermometer RCRO-870	**0**
	**19004813**	USZCZELKA KOMINA Dichtung des Kamins seal of the chimney RCRO-870	**3**
	**19004935**	SZUFLADA SCHUBLADE DRAWER RCRO-870	**3**

Product image	SKU number	Product name	Available quantity
	**19006691**	Opakowanie zewnętrzene 46x53,5x120,5 outer packaging 46x53,5x120,5 Außenverpackung 46x53,5x120,5	**0**
	**19007487**	Zestaw haków hooks set Haken Set	**16**
	**19013360**	Miska na tłuszcz Fat bowl	**5**
	**19019591**	Podstawa pod grzałkę Heater base	**0**
	**19028513**	Gniazdo zasilania Power socket	**0**
	**19028514**	Przełącznik zasilania Power switch	**0**