














- i Please review all available spare parts for this item, then contact us through the webform (found in the Help Centre in our website header). Let us know the SKU of each spare part you're interested in and the quantity you need.
- i The availability of the products may change.

Product image	SKU number	Product name	Available quantity
	<b>19010706</b>	<ul style="list-style-type: none"> <li> Mocowanie podstawy szalki</li> <li> Fastening of pan base</li> </ul>	<span style="color: red;">●</span> <b>0</b>
	<b>19010916</b>	<ul style="list-style-type: none"> <li> Zasilacz 8V</li> <li> 500mA</li> <li> Adapter 8V</li> </ul>	<span style="color: red;">●</span> <b>0</b>
	<b>19013380</b>	<ul style="list-style-type: none"> <li> mocowanie do czujnika</li> <li> Attachment to the sensor</li> </ul>	<span style="color: green;">●</span> <b>6</b>
	<b>19016125</b>	<ul style="list-style-type: none"> <li> Płytką wyświetlacza</li> <li> Display board</li> </ul>	<span style="color: red;">●</span> <b>0</b>